

# RF Dual Color Wall Mounted Controller

09.2830B.04188



- Touch sensitive
- Glass interface(white & black)
- Compatible with all universal series RF receivers
- Control 4 zones synchronously and separately

**Picture**

**Brief introduction of buttons**

Dual color & brightness slide, click to switch

**Note :** This remote controls 4 zones (areas) receivers, each zone can pair with countless receivers.  
**1 receiver can be paired by max 8 different remote controls.**

Operation Voltage	Operation Frequency
12-24V DC/ 100-240V AC	868MHz

**Size**

**Installation**

DC version needs connect with DC power supply

**Wiring diagram**

**Operation**

- Pair with RF receivers:**

Click to Turn on RF remote → Click "Learning Key" on RF receiver → Click a zone button to choose a zone → touch color slide on RF remote, led lights flicker twice means well paired
- Play the remote after pairing:**

Turn on RF remote → Click the paired zone number/numbers → touch color slide or other buttons to do the controlling.
- Save color/scene:**

Turn on RF remote → Click the paired zone number/numbers → Select a color → Hold S1/S2 until light flicker means well saved
- Call up the saved:**

Turn on RF remote → Select zone button which we want to call up → Click S1/S2 button
- How to delete the pairing:**

Power on the RF receiver, hold the "Learning Key" over 3 seconds until connected led lights flicker twice means well deleted.