

PACKING LIST



Table Lamp - 1pc



Adapter - 1pc



User Manual - 1pc



Spanner - 1pc

Operation Cautions:

1. Please do not put the lamp on the high-temperature surfaces, and do not use it in flammable or humid environment, to avoid the breakdown, short circuit etc.
2. The adapter must be under the specialized range.
3. Please steady the base while adjusting the arm.
4. The lamp head can be adjusted freely under the adjustment range. But be cautious and never over adjustment to result in breakdown.


Maintenance

1. Please clear the lamp every two months to keep it smooth and bright.
2. Just use cleaning cloth and water to clean the dust.
3. For the filthy mark, please use cleaning cloth and soap suds.
4. Please do not clean the lamp by high-volatility and high-corrosive liquid which can make it discoloring or broken.



Power off before cleaning.
Please ask for the professional person for checking and repairing when it is broken.
If any abnormal cases, power off rapidly and contact dealer or manufacturer.

LED TABLE LAMP User Manual



Thank you for your purchasing this product.
Please read this instruction carefully to understand its features and safety cautions.

FEATURES

- ◆ Simple design with a touch button
- ◆ Six steps dimming brightness
- ◆ Five modes for CCT
- ◆ 60 minutes timer
- ◆ USB output
- ◆ Memory function for the brightness and temperature
- ◆ Wireless Charger



Wireless Charger



Touch Control



6 Steps Dimming



5 modes CCT




60 mins timer




USB output

PARTS INDICATOR


Wireless Charger





1.If your phone has built-in wireless receiver,it will be charged directly when you put it on the charging zone of the lamp base.




2.If your phone has no built-in wireless receiver, you should buy one. Then connect the receiver to your phone,put your phone on the charging zone of the lamp base,your phone will be charged.



OPERATION GUIDE



USB output for charging your phone and your other compatible devices.



put the body part of the lamp in the hole of the lamp at the base of it with the correct direction according to the illustration image. Then put the screws and use spanner to fix all the lamp. It can be used properly.

- Power on/off: Touch this power button (⏻) to turn on and turn off the lamp. If you do not pull out the adapter, then turning on the lamp, the brightness will be same as last time.
- Brightness adjustment: Touch (◻) button, you can slide adjustment with six steps dimming brightness.
- Lighting mode: Touch this button (Ⓜ) to adjust the color temperature repeatedly, and there are five modes as follows.
- One hour timer: Touch (🕒) button, the indicated light is on, and it means the lamp will be automatically off 1 hour later. When touching again, the indicated light is off and 1 hour timer is canceled.

SPECIFICATIONS

Item	LED Table Lamp
Power	18W
Voltage	AC100-240V. 50/60Hz
Adapter output	DC 12V / 2A
CCT	6500K
	5800K
	4800K
	3800K
	3200K
Lifespan	35000h
CRI	≥80Ra
Center luminance (40cm)	1000LUX
Material	ABS+PC+Aluminum
Operating temperature	-20°~45°
Product size	425×118×455mm
N.W.	670g
Colors	Silver / Black / Dark Gray Dark Red / Dark Orange